

Honeywell 1300 Posim EVO Settings

The following are the default settings for the **Honeywell 1300g** or **1300g-2** to be programmed correctly to work with EVO. They are listed below in the order in which they should be scanned.



DEFAULT.

Standard Product Default Settings



VSUFCR.

**Add CR Suffix
All Symbologies**



C39ASC1.

Full ASCII On